168 MAX LUMENS



INCLUDES

- E3 FLASHLIGHT
- POCKET CLIP
- SPARE O-RINGS
- INSTRUCTION MANUAL



The **PowerTac E3** is the ultimate everyday carrying key chain light. It combines a compact size and amazing 168 lumen maximum light output with only one AAA battery. The E3 also comes with an easy to use interface and three different brightness levels plus strobe. The E3 outputs an amazing 168 lumens on high and 50 lumens on low, which is good for low light situations with super long run time. It's durability, shock resistance and rugged build quality make it the key chain light to go everywhere your adventures take you.

1.2 hrs

LED Type:	Cree XP-G2 R5
Battery:	(1) AAA Battery (Not Compatible with Li-ion)
Size:	Length:79mm Bezel Diameter: 14.5mm Body Diameter: 14.5mm
Weight:	22g (without battery)
Illuminatio	n: 168 Lumens 50 Lumens 168 Lumens 6 hrs 1 7hrs (Strohe)

INTRODUCTION


The Powertac E3 is the ultimate compact keychain light. Small, extremely versatile and light weight, it's the perfect go to light for every day carry. It shares the same CREE LED(XP-G2) as some of the other much bigger lights and also provides a very bright white light. At a maximum output of 168 Lumens, it has set the bar high for the industry to follow. With multiple brightness levels, a push button tail cap, and using one AAA battery, the E3 has set itself apart from its competitors.

USAGE INSTRUCTIONS

To install battery: Remove bezel head and insert one AAA battery into the body tube with the anode (+) facing toward the flashlight head.
Re-attach and tighten bezel head



- 2. To turn the light ON: Push the back switch to click.
- 3. To switch light levels: Half press the back switch to change light levels.



DISCLAIMER

- After long periods of use on the highest setting, the surface area may get hot. Please use caution when using the flashlight in a constant high brightness level. It is recommended to let the flashlight cool down to prevent any injury.
- High intensity light is harmful to human eyes. This product is not meant to be handled by children under the age of 18 without adult supervision.
- Use the highest quality, protected-circuit batteries to insure maximum performance and safety. Consult with the manufacturer regarding any questions or concerns.
- PowerTac's liability is voided if the light is not used in a proper manner or if modified.
- PowerTac reserves the right to change the design and/or specifications of all PowerTac products without prior notice.
- Please do not change batteries at dangerous locations such as gas stations.
- Batteries must only be changed or removed when light is off.
- Do not use or attempt to recharge a disposable CR123 battery! Do not throw the flashlight into a fire as an explosion may occur.

THE POWERTAC NO-HASSLE LIFETIME WARRANTY

PowerTac warrants our illumination tools to be free from defects in workmanship and materials, including any LEDs housed within, for the lifetime of the original parts (the lifetime of the parts are specified by individual parts manufacturers). We will repair or replace your original purchase of these products, at our discretion, if it is determined by us to be defective. Electronics, chargers, and rechargeable batteries are covered for a period of two years with proof of purchase. Normal wear and tear – including lamps burning out, batteries draining, and switches wearing out – is not covered, nor is damage resulting from misuse, abuse, neglect, battery damage, use of other non-approved batteries or altering these products from their original state. Parts and accessories for illumination tools are not covered by this warranty